Temperature & Model Dip-Switch Settings for REU V2626WG ONLY



- Confirm that <u>ALL DIGITS</u> of the model number on the appliance dataplate match one of the model numbers above (including the letters G, B, E & S in the Model Number).
- Water heaters that have "(50)" in the model number or nominated on the front panel of the water heater cannot be adjusted to temperatures above 50°C.



- 1. Dipswitch settings must only be set by an authorised person.
- 2. All dipswitches <u>MUST</u> be set for the particular model in accordance with this Instruction. Incorrect dipswitch settings may result in a dangerous condition or damage to the appliance.
- 3. It is the responsibility of the authorised person changing the dipswitch settings to ensure the installation complies with the requirements of AS/NZS 3500.4 and any local regulations regarding water delivery temperature to areas primarily used for personal hygiene (50°C).

