

Temperature & Model Dip-Switch Settings for HD200i (42 PRESET) - REU VR2632FFUC42 ONLY



- Confirm that ALL DIGITS of the model number on the appliance dataplate match the model numbers above.



- Dipswitch settings must only be set by an authorised person.
- All dipswitches MUST be set for the particular model in accordance with this Instruction. Incorrect dipswitch settings may result in a dangerous condition or damage to the appliance.

Dipswitch Settings

Dip Switches explained & Model Setting

Off On SW 1

1	
2	
3	
4	
5	
6	
7	
8	

Flue length

Temperatures

Gas Pressures

Off On SW 2

1	
2	
3	
4	

Gas Type

Model Type

Gas Pressures

Off On SW 1

1	
2	
3	
4	
5	
6	
7	
8	

Normal Combustion

Off On SW 1

1	
2	
3	
4	
5	
6	
7	
8	

Forced low Combustion

Off On SW 1

1	
2	
3	
4	
5	
6	
7	
8	

Note: After setting gas pressures return both 7 and 8 dipswitches to the OFF position for normal combustion.

Forced High Combustion

Off On SW 2

1	
2	
3	
4	
5	
6	

If the dipswitch bank 2 has 6 switches, Ensure that switches 5 and 6 are in the OFF position

Flue Length

Off On SW 1

1	
2	
3	
4	

Short Flue (Under 2 meters)

Off On SW 1

1	
2	
3	
4	

Extended Flue (Over 2 meters)

Gas Type

Off On SW 2

1	
2	
3	
4	

Natural Gas

Off On SW 2

1	
2	
3	
4	

Propane Gas

Model Type

Off On SW 1

1	
2	
3	
4	
5	
6	
7	
8	

REU-VRM2632FFUC (42)
(HD200i 42 preset)

Off On SW 2

1	
2	
3	
4	

Temperature

Temperature dipswitch settings cannot be adjusted on factory preset 42°C models, Contact TSD for further information

Legend



Black indicates position of switch